




























Leistritz

2408i Setup for TSMS

1. From any display press  until **ACCS** is displayed
2. Press  to show **CODE**
3. Press  to enter passcode (1 is default) Display will read **PASS**
4. Press  until display reads **GOTO**
5. Press  until display reads **FULL**
6. Press  until you come back to the Home Display (Process Variable)
7. Press  until **dSP.b** is displayed
8. Press  until **SP** is displayed
9. Press  until **CMS** is displayed
10. Press  until **ADDR** is displayed
11. Press  until M ADDR is displayed (This is M ADDR designated on I/O list)
12. Press  until **ACCS** is displayed
13. Press  until **Code** is displayed
14. Press  to enter passcode. Display will read **PASS**
15. Press  until display reads **GOTO**
16. Press  until display reads **EDIT**
17. Press  until you come back to the Home Display (Process Variable)
18. Press  until **dSP.b** is displayed
19. Press  until **Altr** is displayed
20. Press  once
21. Press  until **Altr** is displayed
22. Press  until **ACCS** is displayed
23. Press  until **Code** is displayed
24. Press  to enter passcode. Display will read **PASS**
25. Press  until display reads **GOTO**
26. Press  until display reads **OPER**
27. Press  until you come back to the Home Display (Process Variable)
28. Power Meter off and then back on